
Heat Exchange for Light Commercial Large Chassis

0257L00042
0257L00045
0257L00047
0257L00048
0257L00055
0257L00267

ACCESSORY PARTS LIST

RP-HXLC*

This manual is to be used by qualified technicians only.

Important Information

Index

Functional Parts List	3
Illustration and Parts	4 - 5

Views shown are for parts illustrations only, not servicing procedures

Text Codes:

AR - As Required

NA - Not Available

NS - Not Shown

00000000 - See Note

QTY - Quantity Example (QTY 3) (If Quantity not shown, Quantity = 1)

M - Model Example (M1) (If M Code not shown, then part is used on all Models)

Expanded Model Nomenclature:

Example M1 - Model#1 M2 - Model#2 M3 - Model#3

Daikin Manufacturing Company, L.P. is not responsible for personal injury or property damage resulting from improper service. Review all service information before beginning repairs.

Warranty service must be performed by an authorized technician, using authorized factory parts. If service is required after the warranty expires, Daikin Manufacturing Company, L.P. also recommends contacting an authorized technician and using authorized factory parts.

Daikin Manufacturing Company, L.P. reserves the right to discontinue, or change at any time, specifications or designs without notice or without incurring obligations.

For assistance within the U.S.A. contact:

Homeowner Support
Daikin North America, LLC
19001 Kermier Road
Waller, Texas 77484
855-770-5678-Telephone
713-863-2382-Facsimile

For assistance outside the U.S.A. contact:

International Division
Daikin North America, LLC
19001 Kermier Road
Waller, Texas 77484
713-861-2500-Telephone
713-863-2382-Facsimile

Functional Parts

Part

No:

Description:


0163L00000	BECKETT BURNER (QTY 8)
0130F00010	FLAME SENSOR
20261709	IGNITOR
0130M00064	LIMIT
20162904	LIMIT, PRIMARY (M3, M4)
20162903	LIMIT, PRIMARY (M1, M2)
0130M00063	LIMIT, PRIMARY, 140, GOLD (M5, M6)
10123529	MANUAL RESET LIMIT
11112501	PRESSURE SWITCH
0151M00015	VALVE, GAS (HW) VR83

Expanded Model Nomenclature

M1 - 0257L00042
M2 - 0257L00045
M3 - 0257L00047
M4 - 0257L00048
M5 - 0257L00055
M6 - 0257L00267

HEAT EXCHANGE ASSEMBLY

HEAT EXCHANGE AND MANIFOLD ASSEMBLY
MAY DIFFER FROM WHAT IS SHOWN



Ref. Part No: No:	Description:	Ref. Part No: No:	Description:
Image 1:			
41	0154L00025		GASKET-COVER REAR 8
51	0121L00545		COVER-REAR 8 TUBE
91	0131L00014		MOTOR-ID VENT
101	0270L00236		PARTITION TUBE ASSY 7B (M3)
101	0270L00186		PARTITION TUBE ASSY 8B (M1, M5)
101	0270L00237		PARTITION TUBE ASSY-7B SS (M4)
101	0270L00221		PARTITION TUBE ASSY-8B SS (M2, M6)
181	0154L00026		INNER COLLECTOR BOX GASKET
191	0154L00027		OUTER COLLECTOR BOX GASKET
201	0121L00707		COVER-COLLECTOR BOX 7 (M3, M4)
201	0121L00550		COVER-COLLECTOR BOX 8 (M1, M2, M5, M6)
211	0121L00546		CHANNEL-COLLECTOR BOX 8
251	0154L00029		GASKET-COMBUSTION BLOWER
261	0121L00668		FLUE WRAPPER, BACK
281	20162903		LIMIT, PRIMARY (M1, M2)
281	20162904		LIMIT, PRIMARY (M3, M4)
281	0130M00063		LIMIT, PRIMARY, 140, GOLD (M5, M6)
301	11112501		PRESSURE SWITCH
311	A3468601		PRESSURE SWITCH HOSE
321	10123529		MANUAL RESET LIMIT
331	0121L00053		FLAME ROLLOUT BRACKET
341	0121L00548		PLATE-TUBE PANEL 8
351	0154L00028		GASKET-TUBE PANEL 8
381	0121L00930		SUPPORT-HEAT TUBES 2.25
401	0121L02100		FLUE WRAPPER EXIT (M1, M3, M5, M6)
401	0121L00670		FLUE-EXIT WRAPPER (M2, M4)
411	0121L00671		FLUE COVER EXIT
431	0121L00669		FLUE COVER, FRONT
441	0121L00808		SUPPORT-HEAT TUBES 2.25
451	0121L00823		BRACKET-TUBE SUPPORT (QTY 2)
511	20261709		IGNITOR
521	0151M00015		VALVE, GAS (HW) VR83
531	0163L00014		ORIFICE (QTY 8)
541	0130F00010		FLAME SENSOR
561	0163L00033		MANIFOLD-GAS 8 BURNER (M1, M2, M5, M6)
561	0163L00051		MANIFOLD-GAS, 7 BURNER (M3, M4)
571	0163L00000		BECKETT BURNER (QTY 8)
581	0121L00656		BRACKET-7 BURNERS (M3, M4)
581	0121L00635		BRACKET-8 BURNERS (M1, M2, M5, M6)
591	0121G00268		BRACKET-BURNER TOP/BOT (QTY 2)
601	0121L00697		BRACKET GAS VALVE PIPE
611	B1910013		1 1/8" GROMMET
701	0121L00594		BRACKET SECONDARY LIMIT
711	0130M00064		LIMIT
NS	0163L00040		FLUE SCREEN

Expanded Model Nomenclature

M1 - 0257L00042 M2 - 0257L00045 M3 - 0257L00047 M4 - 0257L00048 M5 - 0257L00055 M6 - 0257L00267
--